



System Overview

Factrac® SmartCount™ Edge is an affordable, scalable and easy way to track and visually display your real-time throughput metrics. The plug and play setup is simple and secure. In less than an hour, have your screens showing critical numbers for a single process or operation wide performance. No programming required.


Table of Contents

1. Connections (Page 3)
2. Display Templates (Page 4–5)
3. Selecting View Template (Page 6)
4. Select Main Variable (Page 6)
5. Select Alternate Variable (Page 7)
6. Enable Span Colors (Page 7)
7. Run Screen Overview / Functions (Page 8)
8. Sidebar Functions (Page 9)
 - a. Home
 - b. Settings
 - c. Networking
 - d. Security
 - e. Languages
 - f. System
 - g. Pause
 - h. Start Setup / End Setup
 - i. Open Data Fields
9. Settings (Page 10)
10. Display Data (Page 10)
 - a. Round to Whole Numbers
 - b. Alternative Text Forecolor
 - c. Show Total Time / Run Time
 - d. Show Downtime Status
11. Rate Scale (Page 11)
12. Sensor 1 Count Multiplier (Page 11)
13. Sensor 2 Count Multiplier (Page 11)
14. Count Direction & Starting Count (Page 11)
15. Actual Count 1, Actual Count 2, Target Rate, Total, Actual Total, Time Out, Reset Data (Page 12)
16. Sensor 1 De-bounce On / Off (Page 13)
17. Sensor 2 De-bounce On / Off (Page 13)
18. Encoder Settings (Page 13)
19. Date and Time (Page 14)
20. Shifts (Page 14)
21. Changing Background Colors (15–16)
 - a. Current Downtime Background Color (Page 15)
 - b. Total Downtime Background Color (Page 15)
 - c. Count Percent Background Color (Page 15)
 - d. Percent Complete Background Color (Page 15)
 - e. Net Percent Background Color (Page 15)
 - f. Rate Percent Background Color (Page 15)
 - g. Shift Downtime Background Color (Page 15)
 - h. Current Run Time Background Color (Page 16)
 - i. Total Runtime Background Color (Page 16)
 - j. Downtime Percent Color (Page 16)
22. Optional Data Capture (Page 15–16)
23. Downtime Status Color, Mode and Timer (Page 17)
24. Screen Shot (Page 17)
25. Demo mode (Page 17)
26. Networking (Page 17–20)
27. Security (Page 21)
28. Languages (Page 22)
29. System (page 23)
30. Pause/Resume (Page 24)
31. Start and Stop Setup (Page 25)
32. Downtime Status from Barcode Scan (Page 26)

1. Connections


SmartCount Edge Specs

Blue Light SOLID - Program booted correctly




View of processor: Green Light and Read Light Solid - Good
 Green Light OFF - No 5VDC to processor
 Red Light FLASHING - Power too Low

M12-A SmartCount Input Options




Dry contact:
 Closing pin 2 to pin 3 registers a count



NPN Sensor; where signal return is found on pin 4 of the M12 connector:

These type of sensors will require a M12 crossover adapter



NPN Sensor; where signal return is found on pin 2 of the M12 connector:


There are various sensors that will output on pins 2 and 4 for different signal options. (i.e -PNP and NPN, Light ON and DARK on)

Note: If using open lead cable, do not twist open wires together if plugged into SC Controller. Brown is live 12 Volts, and it will short power supply to SC Controller.

2. Display Templates

The SmartCount PLUS allows you to pick and choose the metrics you want to display on the Run Screen. There are a total of 7 templates to choose from. Display as little or as much as you need to.

3 View Display



4 View Display



6 View Display




8 View Display




11 View Display



14 View Display



18 View Display



3. Selecting View Template

SMARTCOUNT

SmartCount Version
Select Version
4 View Template ← **3. Select Template**

View Selection

Position #1
Main Variable: Total Time
Alternate Variable: Pause and Setup

Position #2
Main Variable: Run Time
Alternate Variable: None

Position #3
Main Variable: Actual Count
Alternate Variable: Down Time Status

Position #4
Main Variable: Actual Count 2
Alternate Variable: None

9:41 am

1. Click Side Bar →

2. Click Setting →

- Home
- Settings
- Networking
- Security
- Languages
- System
- Pause 00:00:00
- Start Setup 00:00:00

FACTRACPRO.COM

4. Select Main Variable

SMARTCOUNT

SmartCount Version
Select Version
4 View Template

View Selection

Position #1
Main Variable: Total Time

Alternate Variable: Run Time
Count Percent

Position #2
Main Variable: Hourly Count Percent
Alternate Variable: Net Percent
Count 1 - Count 2

Position #3
Main Variable: Actual Count
Alternate Variable: Down Time Status

Position #4
Main Variable: Actual Count 2
Alternate Variable: None

9:42 am

Home

Settings

Networking

Security

Languages

System

Pause 00:00:00

Start Setup 00:00:00

FACTRACPRO.COM

5. Select Alternate Variable

The SmartCount PLUS allows you to pick and choose the metrics you want to display on the Run Screen. There are a total of 7 templates to choose from. Display as little or as much as you need to.

SMARTCOUNT

SmartCount Version
Select Version
4 View Template

View Selection

Position #1
Main Variable: Setup
Alternate Variable: Pause and Setup
Current Downtime
Total Downtime

Position #2
Main Variable: Total & Current Downtime
Alternate Variable: Down Time Status
Down Time Percent

Position #3
Main Variable: Actual Count
Alternate Variable: Down Time Status

Position #4
Main Variable: Actual Count 2
Alternate Variable: None

Home
Settings
Networking
Security
Languages
System

Pause 00:00:00
Start Setup 00:00:00

9:43 am

FACTRACPRO.COM

6. Enable Span Colors

Display colors associated with appropriate fields when certain threshold percentages / times are reached. Click the check box to enable

Sensor 2 Debounce On (milliseconds) 5

Sensor 2 Debounce Off (milliseconds) 10

Sensor 2 Debounce On (milliseconds) 5

Sensor 2 Debounce Off (milliseconds) 10

Run Time
Enable Span Colors

Total Time
Enable Span Colors

Optional Data Capture
Utilize Optional Data Entry

Down Time Status
Total: 00:07:39
Down Time Description 1
Total: 00:00:00
Color: Green Type: Flash

Run Time
Enable Span Colors

Gray
0 00 TO 0 02 hours : minutes


Red
0 02 TO 0 03 hours : minutes

Yellow
0 03 TO 0 04 hours : minutes

Blue
0 04 TO 0 05 hours : minutes


Green

7. Run Screen Overview / Functions



- Keyboard in Run Screen Field:** A keyboard symbol in the lower left corner of any field allows you to make changes to the value in that field. Simply click on the keyboard image, enter a new value, save. Field will display the new value.
- Reset:** Right click with a mouse, or on a touch screen, double tap anywhere on the blank portion of the screen. A button will appear, "Clear Values". This will reset the displayed values.
- Open Sidebar:** Click or press on the three lines in the upper right corner of the screen to open the sidebar.

8. Sidebar Functions



- a. **Home:** Click or press on Home icon to close the sidebar and return to run screen. If in any screen other than the Run Screen, click or press the Home icon twice (2 x) to return to the Run Screen.
- b. **Settings:** Click or press on Settings icon to open the Settings Menu.
- c. **Networking:** See the Networking section.
- d. **Security:** See the Security Menu section.
- e. **Languages:** Click or press on Languages icon to open the Languages Setting Menu.
- f. **System:** Click or press on the System icon to open the System screen.
- g. **Pause:** Click or press on Pause/Resume icon to toggle between Pause and Resume modes. The accumulated time is displayed beneath the button.
- h. **Start Setup / End Setup:** Click or press on the Start Setup / End Setup icon to toggle between the two modes. The accumulated time is displayed beneath the button.
- i. **Open Data Fields:** When “Use optional data capture” has been enabled under settings, the fields will appear and can be edited on the sidebar. If data has initially been entered into an Open Data Field through the Settings Menu, the 3 open data fields will display on the sidebar. The 3 Open Data Fields can be edited from the Sidebar.

9. Settings

Click or press on the 3 lines in the upper right hand corner of the screen to open the Sidebar. Click or press on Settings on the sidebar to open the Settings Menu. Click or press the home button on the sidebar, and the SC run screen will display.

10. Display Data

Display Data

Round to whole numbers

Alternate Text Forecolor


Show Total Time and Run Time

Show Down Time Status

- Round to Whole Numbers:** Single decimal point precision can be displayed on relevant data by disabling “Round to whole numbers” in the settings screen.
- Alternative Text Forecolor:** The default red text in display fields can be changed to white by selecting “Alternate Text Forecolor” in the settings screen.
- Show Total Time and Run Time:** This can be enabled on the settings screen with “Show Total Time and Run Time” in the upper row of each screen display.
- Show Down Time Status:** (Available on SC-2,4,5,9,10,11,12,21). This can be enabled/disabled on settings page with the “Show Down Time Status”.

11. Rate Scale

This is used for all SC Display Screens with a Rate Field. Simply, select the rate scale in units per second, minute, or hour. Rate fields like Actual Rate and Target Rate are displayed in the scale selected.



12. Sensor 1 Count Multiplier (Input 1)

The Sensor 1 multiplier is used when the target object detected contains multiple pieces. For example, if you are detecting a box containing 12 cans of spray paint and you want to count the total number of cans, the value would be 12.

Value can be a decimal or whole number. Enter fractions as a decimal $\frac{1}{2}$ as .50 etc. The value can be up to six digits before the decimal and twelve after the decimal.

13. Sensor 2 Count Multiplier (Input 2)

In models SC-7 and SC-9, Sensor 2 displays an independent second count. In models SC-8 and SC-17, the sensor is counting and subtracting waste or rejects as they are diverted off the line. If you keep them in line on the same process, it can be used to net the good product. (Sensor 1 counts all product and Sensor 2 counts the good product after any reject or waste has been removed from the line.)

14. Count Direction and Starting Count (SC-1,2,6,11)

- a. **Count Direction:** Select the Count Direction up or down.
- b. **Starting Count:** Starting Count applies to the value in the Actual Count field. You can change the number to any number. Screen will reset to that number and then system will continue to increment the count from the new starting number. System will increment up or down for these models as selected in Settings Menu. You can also change the count value by using the keyboard in the lower left corner of the run screen Actual Count.

Rate Scale
per minute

Sensor 1 Count Multiplier
1

Count Direction
up
down

An arrow points to the 'up' option in the Count Direction dropdown menu.

15. Actual Count, Actual Count 2, Target Rate, Total, Actual Total, Timeout, Reset Data

Actual Count (Input 1): Shows value displayed on SC run screen for this Field. Value will increment while in the Settings Menu. To change the value, click or press on keyboard to right and enter new value and hit enter. New value will display and SC controller will increment starting from this value.

Actual Count 2 (Input 2): Shows value displayed on SC run screen for this Field. Value will increment while in the Settings Menu. To change the value, click or press on keyboard to right and enter new value and hit enter. New value will display and SC controller will increment starting from this value.

Target Rate: The Target Rate is the rate you set as your goal. Enter the number to be used with the desired rate scale (see #5).

Total: Shows value displayed on Run Screen for this Field. Value will increment while in the Settings Menu. To change the value, click or press on the keyboard to right and enter new value and hit enter. The new value will display and will increment starting from this value.

Timeout (seconds): Timeout is used for all screen displays with Down Time Fields. Enter the value for the amount of time in seconds, after pulses have stopped and before a model begins showing down time. Example: if you would like a model to wait 15 seconds from the stop of a line and before the screen shows down time, then you would enter 15 in the Timeout setting.

Reset Data: There are 4 ways to Reset the counts on the display. First, click the “Reset Data” button on the Settings Menu. Second, right click with a mouse, or on a touch screen, double tap anywhere on blank portion of the screen and a button will appear to “Clear Values”, then click on the button. Third, push and hold the SC Controller button for 5+ seconds. Fourth, if using an SC model which only requires 1 input, a remote input can be connected to Input 2. Remote input can be on any length cable and be a push button, foot pedal, switch, or sensor; hold signal for 5+ seconds to Reset.

Actual Count
0

Actual Count 2
0

Target Rate (per minute)
60

Total
1000

Actual Total

Timeout (seconds)
2

Reset Data
Reset Data

16. Sensor 1 (Input 1) De-bounce On/Off

Sensor 1 De-bounce On: This is the value in milliseconds (ms) that the input signal needs to be on before the SC controller accepts the signal. Default is 5 ms. If running at speeds over 1,000 pulses per minute, set value to zero ('0').

Sensor 1 De-bounce Off: This is the value in milliseconds (ms) that the input signal needs to be on before SC controller will accept another signal. Default is 10 ms. If running at speeds over 1,000 pulses per minute, set value to zero ('0').



17. Sensor 2 (Input 2) De-bounce On/Off (see image above)

Sensor 2 De-bounce On: This is the value in milliseconds (ms) that the input signal needs to be on before the SC controller accepts the signal. Default is 5 ms. If running at speeds over 1,000 pulses per minute, set value to zero ('0').

Sensor 2 De-bounce Off: This is the value in milliseconds (ms) that the input signal needs to be on before SC controller will accept another signal. Default is 10 ms. If running at speeds over 1,000 pulses per minute, set value to zero ('0').

Sensor 2 Debounce On (milliseconds)

Sensor 2 Debounce Off (milliseconds)

18. Encoder Settings: (SC-5,15,22)

- Encoder Pulses per Revolution:** Enter the number of pulses encoder sends for 1 revolution of the encoder wheel. If using the standard SmartCount encoder, the setting value is 2. Please note, higher resolution encoders can be provided. Maximum pulse rate of SC controller is 2,000 pulses per minute.
- Encoder Distance per Revolution:** Enter the distance the wheel travels in one revolution (circumference) as measured in the selected Unit Scale. If using the standard SmartCount encoder the setting value is 12.
- Encoder Unit Scale:** Select scale in inches for Imperial (feet or inches) or millimeters for Metric (meters or centimeters) that the distance of one wheel revolution is measured by. If using the standard SmartCount encoder, the setting is inches.

Rate Scale

Distance Scale

Target Rate (per minute)

Timeout (seconds)

Distance Scale

Distance Scale

19. Date and Time

The Time and Date can be set to display or not display on the run screen. If System Time Enabled is checked it will display. If not checked it will not display. The SC controllers will display the date and time in the lower left hand corner of the screen. The SC controllers do not have battery back-up. Upon installation go to the Settings Menu and set time, date, and time zone. **IMPORTANT** - Click the Checkmark when done making a change. If power is turned off or unit is unplugged, the operator will need to reset the time and date.

Date and Time

Date

March	21	2019
-------	----	------

Time

2	56	PM
---	----	----

Time Zone

(UTC-06:00) Central Time (US & Canada) ▾

System Time Enabled

Shifts

3 Scheduled Times ▾

12	00	AM
10	00	AM
4	00	PM

January	30	2016
February	1	2017
March	2	2018
April	3	2019
May	4	2020
June	5	2021
July	6	2022
August	7	2023

System Time Enabled

Shifts

4 Scheduled Times ▾

7	00	AM
3	30	PM
11	00	PM
12	00	PM

20 Shifts

With System Time Enabled, this set of fields allows you to define up to four auto reset shift set points for the start of each shift. The count and timer fields will be reset to zero at each set point.

Time

10	13	AM
----	----	----

Time Zone

(UTC-06:00) Central Time (US & Canada) ▾

System Time Enabled

Shifts

4 Scheduled Times ▾

7	00	AM
3	30	PM
11	00	PM
12	00	PM

→

Total Down Time

Gray

0	00	TO	0	00	hours : minutes
---	----	----	---	----	-----------------

21. Changing Background Colors

This set of fields allows you to set the display field background color for a customer selected value range. After setting value range, be sure to click or press the checkmark to save. Colors are Gray, Green, Blue, Yellow, Red. When field value falls in this range, background color will automatically change to selected color.

a. Current Down Time

Current Down Time

Gray
 TO hours : minutes

Green
 TO hours : minutes

Blue
 TO hours : minutes

Yellow
 TO hours : minutes

Red
 TO hours : minutes

b. Total Down Time

Total Down Time

Gray
 TO hours : minutes

Green
 TO hours : minutes

Blue
 TO hours : minutes

Yellow
 TO hours : minutes

Red
 TO hours : minutes

c. Count Percent

Count Percent

Gray
 TO

Red
 TO

Yellow
 TO

Blue
 TO

Green
 TO

d. Percent Complete

Percent Complete

Gray
 TO

Red
 TO

Yellow
 TO

Blue
 TO

Green
 TO

e. Net Percent

Net Percent

Gray
 TO

Red
 TO

Yellow
 TO

Blue
 TO

Green
 TO

f. Rate Percent

Rate Percent

Gray
 TO

Red
 TO

Yellow
 TO

Blue
 TO

Green
 TO

g. Rate Percent

Shift Down Time

Gray
 TO hours : minutes

Green
 TO hours : minutes

Blue
 TO hours : minutes

Yellow
 TO hours : minutes

Red
 TO hours : minutes

h. Current Run Time

Current Run Time

Gray
 TO hours : minutes

Red
 TO hours : minutes

Yellow
 TO hours : minutes

Blue
 TO hours : minutes

Green
 TO hours : minutes

i. Total Run Time

Total Run Time

Gray
 TO hours : minutes

Red
 TO hours : minutes

Yellow
 TO hours : minutes

Blue
 TO hours : minutes

Green
 TO hours : minutes

j. Down Time Percent

Down Time Percent

Green
 TO

Gray
 TO

Blue
 TO

Yellow
 TO

Red
 TO

22. Optional Data Capture

Optional Data Entry fields, up to 6 are only visible on navigation bar when user enables “Utilize Optional Data Entry” in the settings screen. SC units with integrated touchscreen display can view these fields by scrolling down on the navigation bar, sweeping up motion on touch screen will scroll the navigation bar.

Red
 TO

Optional Data Capture
 Utilize Optional Data Entry ←

Down Time Status
 Total: 00:00:00

Quality
 Total: 00:00:00
 Color: Type:

Entry fields will appear in sidebar

00:00:00
 Start Setup
 00:00:00

Optional Data Capture
 Open Field One

Open Field Two

Open Field Three

Open Field Four

Open Field Five

Open Field Six

If you are utilizing the barcode reader option with your SmartCount™ device, you can now quickly add data to the Optional Data Capture Fields.

Start by scanning the “Optional Entry #1” (1) barcode with your barcode reader and then scan your actual barcode (2). The text / alpha data will automatically populate in that field. A confirmation message will be displayed on the screen momentarily.

Repeat for all remaining fields (3 & 4)

If you scanned the incorrect entry barcode, simply click the “cancel Entry” field and start over.

The diagram illustrates the process of entering data into the Optional Data Capture fields. It shows six 'Optional Entry' barcodes (labeled 1 through 6) with their respective alphanumeric codes (e.g., 0799000001 for Optional Entry #1). A 'Sample Job Ticket' shows a barcode with the alphanumeric code '1 2 3 4 5 6'. A 'Cancel Entry' barcode with code '0799000007' is also shown. A screenshot of the 'Optional Data Capture' screen shows six open fields. The first field contains '123456', the second contains 'Op ID 6789', and the sixth field contains '56' with a close button (X) to its right.

If you utilize a single barcode for multiple data/alpha fields, set your barcode to the format shown below. Using the barcode reader, scanning the barcode you created and it will automatically load each optional data field.

The diagram shows a 'Combo Field Entry Code' represented by a QR code. Below it, the format for the code is given as: SETDATA_ENTRY01_ENTRY02_ENTRY03_ENTRY04_ENTRY05_ENTRY06. An example code is provided: SETDATA_John Doe_8914321564_Muffler Bearings_912315542_Second Shift Part Run_56. A screenshot of the 'Optional Data Capture' screen shows the fields populated with data from the example code: 'John Doe', '8914321564', 'Muffler Bearings', '912315542', 'Second Shift Part Ru', and '56' with a close button (X) to its right.

Barcode documents are online at <https://www.factracpro.com/technical-docs>

23. Downtime Status Color, Mode, and Timer

Downtime Status Color, Mode and Timer: For each of the 9 possible Downtime Statuses (states), you can select background display color from Gray, Green, Blue, Yellow, or Red. You can also select the color Mode – “steady” or “flashing”. The color along with the mode allows each of the 9 Downtime Statuses to have a unique background visual on the run screen. Making it easy for staff to know the Downtime Status. After setting value range, be sure to click or press the checkmark to save. When a status is selected a timer will increment time for each event. The aggregated times can be seen in the status windows when the status is selected. You can view all down time status times on the settings page. The total is displayed under Down Time Status and each individual status will show its own aggregated value under the description.

24. Screen Shot

When enabled, you can save Screenshots to a customer provided External USB Drive. Enter the frequency of each save in minutes in the data entry box.

25. Demo Mode

Allows the user to simulate a live environment. The sensor input rates may be changed.

26. Networking

- a. **Device Name:** The default name is SmartCount. To change the device name select the on screen keyboard and enter your desired name. Select Save to apply the change.
- b. **Time Sync Server:** When connected to the internet and System Time is enabled. The SmartCount will sync the time with time.windows.com. To change the Time Sync Server, select the on screen keyboard and enter your desired internal or external network time server. Select Save to apply the change.
- c. **DHCP Configuration:** DHCP (automatic addressing) is Enabled is the default and is used to provide quick, automatic, and central management for the distribution of IP addresses within a network from the router. If you want a Static IP Address, change the setting to Disabled and enter the appropriate data for your network.
 - IP address
 - Subnet Mask
 - Default Gateway
 - Preferred DNS Server
 - Alternate DNS Server

- d. **Scoreboard:** The default is Disabled. To Enable place a Check in the box next to Enabled. When enabled, you will see Unit ID, and you can select from ID 1-10. Each ID can display up to 16 SmartCounts for a total of 160. On the Scoreboard you can select the number of SmartCounts that can be viewed per screen; 2, 4, 6, 9, 12 or 16 per ID. The Position Index selection will direct which position on the ID that this SmartCount will display within. An individual SmartCount reports to one ID.

ScoreBoard
 Enabled

Unit ID

Position Index

ScoreBoard
 Enabled

Unit ID

2
3
4
5
6
7
8
9
10

Disabled

MySQL Push

ScoreBoard
 Enabled

Unit ID

Position Index


8
9
10
11
12
13
14
15
16

Disabled


- e. **Data Push:** The SmartCount Edge can stream real time data to a SmartCount CSV, MySQL, SQL, and the IoT Cloud. You can select the frequency in minutes by selection from the pull down menu in 1, 5, 10 or 15 minutes. The data stream will vary based on the display screen that is selected.
- f. **MQTT Data Push:** MQTT is available on all SmartCount units v3.1.0.0 and later. This means the SmartCount unit can stream real time data analytics to the IoT Cloud. The MQTT Client software within the SmartCount units currently supports QOS level 0 messages over an unencrypted TCP connection. SmartCount units do not support MQTT WebSocket or SSL/TLS encryption. The default setting is Disabled. Step by step directions are available on the factracpro.com website.
- g. **DSC CSV Push:** DSV CSV push is available on all SmartCount units v3.1.0.0 and later. The CSV generator is a plug and play solution for data collection and makes managing your data collection easy. Disabled is the default. When enabled, the DSC CSV Push Mode field will be shown.
- h. **DSC CSV Push Mode:** Auto is the default. When Auto is selected, DHCP (automatic addressing) is enabled. DHCP is used to provide quick, automatic, and central management for the distribution of IP addresses within a network from the router. If you want a Static IP Address, change the setting to Static and enter the appropriate Static IP address for your SmartCount CSV.

Remote access and edit In version 4.2.2.0 and above, you can now access and edit a SmartCount™ device remotely from any supported browser* on the same network.


(*Supported browsers: Google Chrome for Windows Version 78 or greater, Google Chrome for Android Version 78 or greater, Mozilla Firefox for Windows Version 70 or greater, Microsoft Internet Explorer for Windows Version 11 or greater, Microsoft Edge for Windows Version 44 or greater, Mozilla Firefox IOS version 20 or greater, Safari on IOS 12 or greater.)




Gather the information for Remote Interface (noted in the image below)




From your internet browser on a computer connected to the same network, enter **http:// ip address** (enter the actual ip address)




You will be asked for the username and password. The default is; Username = factrac, Password = remote.



From here you can now make changes to the settings and parameters remotely just as if you were at the actual SmartCount™ device.



27. Security




1. To enable **Security**, check the box next to Enable Security.
2. To Enable **Login on Startup**, check the box next to Show Login on Start-up.
3. There are three **User levels**. Guest, Operator and Manager.
 - a. **Guest** can view the run screen
 - b. **Operator** can engage with the Run Screen and Sidebar fields.
 - c. **Manager** has full access to all fields and settings.


The SmartCount stores one four digit numerical password for each user level. You can choose to have a password for the Operator and Manager or the Operator or Manager. The Guest account does not have a password. If you have not set-up a password for the Operator or Manager accounts, simply click on Sign In. When Security has been enabled you will see Switch User and the User Level that is currently logged in on the sidebar.

A Security bypass can be triggered with a USB keyboard by holding CTRL and P on startup when you see the factrac logo on the screen, this disables security. When activated you will see the Security feature disabled - Release Keys to Continue message, you have bypassed Security. If the password has been forgotten, you will need to reset the SmartCount to its factory image to reset the device and the software.


28. Languages



To change a default label text, scroll down to the default Label and click or press on the keyboard to the right of the Label. Enter the new customer specific text in any language. The new text string will display and save in the box to the right of the default Label. Click or press the Home button on the Sidebar. The SC run screen will display the new text label. Please note this menu will show all possible default Labels for all SC models. Many Labels will not be available for your specific SC model. Making a change to a Label not available for your Model will have no impact on the Run Screen.



29. System



Device Name: This field displays the Device Name as entered in the Networking Tab.

Version: This is the current version of software.

Internet: This field will show Not Connected or Connected (if it can reach the Time Sync Server)

MAC Address:

Networking Data: These fields show the current status of your device.

- IP Address
- Default Gateway
- Subnet
- Preferred DNS
- Alternate DNS
- Time Sync Server
- MySQL Push
- MQTT Push
- Refresh – This update the network settings of your device


System Information: System screen provides software version number and SC Controller MAC Address.

Update: If SC Controller requires an update or new model number upgrade, you will be sent a USB drive. Leave controller powered on and insert USB drive in any of the 4 USB ports on the SC Controller. Press the “Update” button on the System Screen. Controller will auto load the update or upgrade. Screen will go black, then the controller will restart. When done restarting, the update or upgrade will be active.

Reset Device to Factory settings: To reset your SmartCount to the original factory image you will need an USB keyboard connected to your SmartCount. This will wipe all saved settings and languages. The activation and unit version is retained. Restart the SmartCount by power cycling the device with the power switch. When you first see the Factrac logo, hold down the CTRL and W key until the following message is displayed “Data Clear Successful - Release Keys to Continue”. If no confirmation is displayed, power-cycle the unit and try again.

30. Pause / Resume

This feature allows the device to be paused, the Total time will continue to increment but the Target Count will not increment when in Pause mode. Examples for use would be after set-up and before production starts or for operators to pause and resume the system during break times. This is typically used if operations don't want breaks and lunch times to impact the target count through-out the shift. An alternative way to put the SmartCount into Pause mode is to use an input on Input 2. Contact of less than 5 seconds will pause the device, if longer than 5 seconds the SmartCount will reset.




With the barcode reader option, you can pause/resume the SmartCount™ from a simple scan of the barcode. Simply scan the Pause/Resume barcode to pause and then click it again to resume.



31. Start and Stop Setup

This field captures the amount of time each job requires for setup and reports the data along with all operation data.



With the barcode reader option, you can start and stop setup of the SmartCount™ from a simple scan of the barcode and reset the values for each new job. Simply scan the Setup Start/Stop barcode to start setup and scan again to stop.









Barcode documents are online at <https://www.factracpro.com/technical-docs>

32. Downtime Status from Barcode Scan

With the barcode reader option, you can pause/resume the SmartCount™ from a simple scan of the barcode. Simply scan the Pause/Resume barcode to pause and then click it again to resume.

Simply rename your downtime reasons by going to the Languages menu and entering the appropriate text in each field (sample shown below.)

- Down Time Description 1**
- Down Time Description 2**
- Down Time Description 3**
- Down Time Description 4**
- Down Time Description 5**
- Down Time Description 6**

Out of Product	
Machine Maintenance	
Machine Down	
Waiting on Packaing Materials	 <input type="text" value="x"/>
	
	

Then, when a downtime event occurs, simply use the barcode reader to scan the appropriate barcode.

Down Time Selection Codes



Barcode documents are online at <https://www.factracpro.com/technical-docs>

